

TECHNICAL INFORMATION BULLETIN

Subject: Single Cable/Two-Tuner Receiver Installation Using DISH Pro Plus Equipment

To use a single cable to feed both tuners of a DISH Pro Plus (DP Plus) two-tuner receiver, a DP Plus separator must be used in conjunction with either a DP Plus 44 switch or DP Plus Twin LNBF.

A splitter or diplexer can not be used in place of a DP Plus separator.

DP Plus two-tuner receivers include the DISH 322, DISH Player-DVR 522, DISH 721, and DISH Player-DVR 921, and any other future receiver with the DP Plus logo.

The DP Plus single cable solution will not work to feed two separate single-tuner receivers, such as two DISH 311s. However, a DP Plus single cable can be used to feed one single tuner receiver, such as one DISH 311.

Additional information on DP Plus technology can be found on the Retailer Website (<http://retailer.echostar.com>).

